

Tune

BORN IN THE BLACK FOREST BUILT TO ENJOY NATURE



Rolf Drehschaltriff für Rohloff-Nabe

Gebrauchsanleitung

Achtung! Bitte lesen Sie die gesamte Anleitung aufmerksam durch, bevor Sie das Produkt in Gebrauch nehmen.

Technische Daten:

Material: Aluminium 7075, CNC gefertigt
Gewicht: ca. 20g (ohne Griffgummi)

Montageanleitung

Zum Einfädeln des Schaltzuges muss die Klemmschellenschraube ca. 5 Umdrehungen herausgedreht werden, um die Drehbegrenzung aufzuheben. Dann den Griffgummi drehen, bis in den Bohrungen für die Schaltzüge die Veriefung für das Schaltzugende zu sehen ist. Schaltzug mit dem Endstück voraus in die Bohrung schieben und den Dreingriff so verdrehen, dass sich das Schaltzugende korrekt in die Veriefung im Griffgummi setzt. Wenn die Züge korrekt sitzen kann die Schraube am Gehäuse angezogen werden.

Bei beiden Schrauben reicht sehr wenig Drehmoment. (ca.0,5Nm). Die Lenkerklemmung so lange festziehen, bis sich der Griff gerade nicht mehr auf dem Lenker verdrehen kann. Bei Karbonlenkern empfehlen wir unsere Karbon-Montagepaste.

Dann den Schaltzug wie gewohnt zur Rohloffnabe verlegen, dabei müssen noch die schwarzen Endstücke in das Griffgehäuse gesteckt werden, diese bilden den Zuganschlag. Die Zugendstücke, die den Zügen beiliegen werden nicht benötigt.

Gebrauchshinweis

Ohne montierten Griffgummi nicht das Bike auf den Kopf (Lenker!) stellen, da der Griffgummi verhindert, dass sich das Gehäuse bei Belastung verformt.

Garantie:

Ausgehend von dem Kaufdatum gewähren wir zwei Jahre Garantie. Garantieansprüche können nur unter Vorlage einer Händlerrechnung (Kopie) geltend gemacht werden. Die Garantie schließt Material- und Produktionsfehler ein, nicht aber Schäden, welche durch:

- einsatzbedingten Verschleiß
- unsachgemäßen Einsatz
- Nichtbeachtung der Gebrauchshinweise
- nicht fachgerechter Reparatur und Wartung

Garantieansprüche müssen direkt vor Ort geklärt werden und unterliegen dem Ermessen der Firma *Tune U. Fahl*. Die Firma *Tune U. Fahl* haftet aus dieser Garantie nicht auf Schadenersatz, insbesondere nicht für indirekte unfallbedingte Schäden, mittelbare Schäden und Folgeschäden.

Eine Gewährleistung auf Farbkonstanz können wir nicht geben. Farbige Teile können bei Sonneneinstrahlung ausbleichen.

Die Zufriedenheit unserer Kunden ist uns sehr wichtig! Deshalb handhaben wir Probleme mit unseren Produkten, auch außerhalb des Garantieanspruches, meist sehr kulant. Wir sind bekannt für eine schnelle Reklamationsabwicklung.

Bitte senden Sie nur gereinigte Teile ein (Lauräcker ohne Kasette, Reifen & Bremsen) und legen Sie bitte ein kurzes Anschreiben (inkl. Kontaktdaten) sowie eine Rechnungskopie der Sendung bei.

Tune U. Fahl, Im Mittelfeld 18, 79426 Buggingen

Tele. 07631 - 74 807 - 40
Fax. 07631 - 74 807 - 58

service@tune.de

www.tune.de

Außerhalb Deutschlands bitte Ihren zuständigen Distributor kontaktieren!

Tune

BORN IN THE BLACK FOREST BUILT TO ENJOY NATURE



Rolf Drehschaltriff für Rohloff-Nabe

Gebrauchsanleitung

Achtung! Bitte lesen Sie die gesamte Anleitung aufmerksam durch, bevor Sie das Produkt in Gebrauch nehmen.

Technische Daten:

Material: Aluminium 7075, CNC gefertigt
Gewicht: ca. 20g (ohne Griffgummi)

Montageanleitung

Zum Einfädeln des Schaltzuges muss die Klemmschellenschraube ca. 5 Umdrehungen herausgedreht werden, um die Drehbegrenzung aufzuheben. Dann den Griffgummi drehen, bis in den Bohrungen für die Schaltzüge die Veriefung für das Schaltzugende zu sehen ist. Schaltzug mit dem Endstück voraus in die Bohrung schieben und den Dreingriff so verdrehen, dass sich das Schaltzugende korrekt in die Veriefung im Griffgummi setzt. Wenn die Züge korrekt sitzen kann die Schraube am Gehäuse angezogen werden.

Bei beiden Schrauben reicht sehr wenig Drehmoment. (ca.0,5Nm). Die Lenkerklemmung so lange festziehen, bis sich der Griff gerade nicht mehr auf dem Lenker verdrehen kann. Bei Karbonlenkern empfehlen wir unsere Karbon-Montagepaste.

Dann den Schaltzug wie gewohnt zur Rohloffnabe verlegen, dabei müssen noch die schwarzen Endstücke in das Griffgehäuse gesteckt werden, diese bilden den Zuganschlag. Die Zugendstücke, die den Zügen beiliegen werden nicht benötigt.

Gebrauchshinweis

Ohne montierten Griffgummi nicht das Bike auf den Kopf (Lenker!) stellen, da der Griffgummi verhindert, dass sich das Gehäuse bei Belastung verformt.

Garantie:

Ausgehend von dem Kaufdatum gewähren wir zwei Jahre Garantie. Garantieansprüche können nur unter Vorlage einer Händlerrechnung (Kopie) geltend gemacht werden. Die Garantie schließt Material- und Produktionsfehler ein, nicht aber Schäden, welche durch:

- einsatzbedingten Verschleiß
- unsachgemäßen Einsatz
- Nichtbeachtung der Gebrauchshinweise
- nicht fachgerechter Reparatur und Wartung

Garantieansprüche müssen direkt vor Ort geklärt werden und unterliegen dem Ermessen der Firma *Tune U. Fahl*. Die Firma *Tune U. Fahl* haftet aus dieser Garantie nicht auf Schadenersatz, insbesondere nicht für indirekte unfallbedingte Schäden, mittelbare Schäden und Folgeschäden.

Eine Gewährleistung auf Farbkonstanz können wir nicht geben. Farbige Teile können bei Sonneneinstrahlung ausbleichen.

Die Zufriedenheit unserer Kunden ist uns sehr wichtig! Deshalb handhaben wir Probleme mit unseren Produkten, auch außerhalb des Garantieanspruches, meist sehr kulant. Wir sind bekannt für eine schnelle Reklamationsabwicklung.

Bitte senden Sie nur gereinigte Teile ein (Lauräcker ohne Kasette, Reifen & Bremsen) und legen Sie bitte ein kurzes Anschreiben (inkl. Kontaktdaten) sowie eine Rechnungskopie der Sendung bei.

Tune U. Fahl, Im Mittelfeld 18, 79426 Buggingen

Tele. 07631 - 74 807 - 40
Fax. 07631 - 74 807 - 58

service@tune.de

www.tune.de

Außerhalb Deutschlands bitte Ihren zuständigen Distributor kontaktieren!

Tune

BORN IN THE BLACK FOREST BUILT TO ENJOY NATURE



Rolf Twist Shifter for Rohloff-Hub

User Manual

Attention! Please read the entire user manual carefully before using the Rolf twist shifter!

Technical Specifications:

Material: Aluminium 7075, CNC machined
Weight: approx. 20g (without rubber grip)

Assembly Instructions

In order to assemble the gear cable, the clamp screw needs to be turned anti-clockwise for about 5 turns in order to release the rotational limiter. Then, twist the rubber grip until you can see the recess for the cable end through the cable holes. Now, insert the cable end and twist the rubber grip such that the end of the cable correctly engages with the recess for the cable end. When the cables are correctly fitted, the screw in the housing can be tightened.

For both screws a very low torque is sufficient (approx. 0.5Nm). Tighten the handlebar clamp screw only as much as is needed so that the twist shifter can only just not be turned on the handlebar. We recommend using our carbon friction paste on all carbon handlebars.

Now route the cable to the Rohloff hub as usual. The enclosed cable end is to be used in the twist shifter housing. You will not require any cable ends supplied with the cables.

Tune

BORN IN THE BLACK FOREST BUILT TO ENJOY NATURE



Rolf Twist Shifter for Rohloff-Hub

User Manual

Attention! Please read the entire user manual carefully before using the Rolf twist shifter!

Technical Specifications:

Material: Aluminium 7075, CNC machined
Weight: approx. 20g (without rubber grip)

Assembly Instructions

In order to assemble the gear cable, the clamp screw needs to be turned anti-clockwise for about 5 turns in order to release the rotational limiter. Then, twist the rubber grip until you can see the recess for the cable end through the cable holes. Now, insert the cable end and twist the rubber grip such that the end of the cable correctly engages with the recess for the cable end. When the cables are correctly fitted, the screw in the housing can be tightened.

For both screws a very low torque is sufficient (approx. 0.5Nm). Tighten the handlebar clamp screw only as much as is needed so that the twist shifter can only just not be turned on the handlebar. We recommend using our carbon friction paste on all carbon handlebars.

Now route the cable to the Rohloff hub as usual. The enclosed cable end is to be used in the twist shifter housing. You will not require any cable ends supplied with the cables.

Note

Do not turn the bike on its head (handlebar!) when no rubber grip is on the twist shifter. The rubber grip prevents any deformations upon applied loads.

Warranty:

We grant a two year warranty from the date of purchase. Warranty claims can only be made if a copy of an original retailer invoice is presented. The warranty includes material defects and manufacturing faults, but not damages caused by

- normal wear
- unintended use
- disregarding the service instructions/ user manual
- unprofessional repair and maintenance work

Warranty claims have to be sent in to the local TUNE distributor and are subject to the assessment of TUNE U. Fahl. Based on this warranty, the company TUNE U. Fahl is not liable for compensation, especially not for indirect damage caused by accidents, collateral damage and consequential damage. We cannot guarantee a consistency of colours because colours will be bleached by sunlight.

The satisfaction of our customers is very important to us! Therefore, we usually handle problems with our products with goodwill, even if the case is not covered by our warranty. We are known for our quick handling of warranty issues.

Please send us only clean parts (wheels without cassettes and tires) and include a brief cover letter with a description of the problem or defect, your contact information and a copy of the invoice.

Tune U. Fahl, Im Mittelfeld 18, 79426 Buggingen

Tel. 07631 - 74 807 - 40

Fax. 07631 - 74 807 - 58

service@tune.de

www.tune.de

Outside Germany, please contact your country's distributor first!

Note

Do not turn the bike on its head (handlebar!) when no rubber grip is on the twist shifter. The rubber grip prevents any deformations upon applied loads.

Warranty:

We grant a two year warranty from the date of purchase. Warranty claims can only be made if a copy of an original retailer invoice is presented. The warranty includes material defects and manufacturing faults, but not damages caused by

- normal wear
- unintended use
- disregarding the service instructions/ user manual
- unprofessional repair and maintenance work

Warranty claims have to be sent in to the local TUNE distributor and are subject to the assessment of TUNE U. Fahl. Based on this warranty, the company TUNE U. Fahl is not liable for compensation, especially not for indirect damage caused by accidents, collateral damage and consequential damage. We cannot guarantee a consistency of colours because colours will be bleached by sunlight.

The satisfaction of our customers is very important to us! Therefore, we usually handle problems with our products with goodwill, even if the case is not covered by our warranty. We are known for our quick handling of warranty issues.

Please send us only clean parts (wheels without cassettes and tires) and include a brief cover letter with a description of the problem or defect, your contact information and a copy of the invoice.

Tune U. Fahl, Im Mittelfeld 18, 79426 Buggingen

Tel. 07631 - 74 807 - 40

Fax. 07631 - 74 807 - 58

service@tune.de

www.tune.de

Outside Germany, please contact your country's distributor first!