

Es versteht sich wohl von selbst, Karbontasse + Untertasse für den Leichtbau fan ein Muss.

Material	Karbon
Füllmenge	420 ml
ø Tasse	11,5 cm
ø Untertasse	16,0 cm
Gewicht	270 g

Die Tasse wurde auf Lebensmittelechtheit geprüft.



Gebrauchshinweise

- Unsere „Ruhrpott“- Tasse haben wir auf Lebensmittelechtheit testen lassen. Trotzdem ist zu empfehlen, die Tasse vor Gebrauch mindestens drei Mal mit kochendem Wasser auszuspülen.
- Achten Sie vor jedem Gebrauch der Tasse und Untertasse auf Beschädigungen, bei Rissen, Brüchen oder anderen Schäden sollte die Tasse umgehend aussortiert werden.
- Die Tasse und Untertasse kann zum Servieren von Getränken und Lebensmitteln verwendet werden, auch heiße Speisen und Getränke stellen kein Problem dar.
- Sollte die Untertasse als Teller verwendet werden, achten sie darauf die Karbonoberfläche nicht zu beschädigen (z.B. durch ein Messer).
- Achtung, nicht in den Backofen oder die Mikrowelle geben!
- Bitte die Tune Ruhrpott Karbontasse und Untertasse nicht in die Spülmaschine geben. Zum Reinigen genügt Spülmittel und Wasser.

Garantie:

Ausgehend vom Kaufdatum gewährt Tune zwei Jahre Garantie auf Material und Produktionsfehler. Garantieansprüche können nur unter Vorlage einer Händlerrechnung (Kopie) geltend gemacht werden.

Kein Anspruch auf Garantieleistungen besteht bei:

- einsatzbedingter Abnutzung von Verschleißteilen
- unsachgemäßem Gebrauch oder unsorgfältiger Behandlung
- Nichtbeachtung von Gebrauchshinweisen
- unsachgemäßen Reparatur-, Montage-, oder Wartungsarbeiten oder Nachlässigkeit

Garantieansprüche müssen direkt vor Ort geklärt werden und unterliegen dem Ermessen der Firma Tune. Die Firma Tune haftet aus dieser Garantie nicht für Schadensersatz, insbesondere nicht für indirekte unfallbedingte Schäden, mittelbare Schäden und Folgeschäden. Eine Gewährleistung auf Farbkonstanz können wir nicht geben. Eloxierte Tune Produkte können bei Sonneneinstrahlung ausbleichen.

Zur Garantieabwicklung melden Sie den Fall bitte online an (www.tune.de/Garantie) und schicken Sie das Tune Produkt mit Rechnungskopie und Schadensbericht ein.

Tune GmbH
Im Mittelfeld 18 | 79426 Buggingen

service@tune.de
www.tune.de



Außerhalb Deutschlands bitte Ihren zuständigen
Distributor kontaktieren!



BORN IN THE BLACK FOREST BUILT TO ENJOY NATURE

Service

Warranty:

Tune grants a two year warranty from the date of purchase on material defects and production errors. Claims can only be made if a copy of an original sales invoice is presented.

There is no claim for warranty services for:

- normal wear
- improper use or careless treatment
- disregarding the service instructions
- inappropriate repair, assembly, or maintenance works or negligence

Warranty claims have to be sent to the local Tune distributor and are subject to the assessment of Tune. Based on this warranty, the company Tune is not liable for compensation, especially not for indirect damage caused by accidents, collateral damage and consequential damage.

Defect complaints – please register the complaints online (www.tune.de/en/warranty) and send us the part. Complaints shall always be accompanied by a detailed description of the defect and a copy of an original sales invoice.

Tune GmbH
Im Mittelfeld 18 | 79426 Buggingen

service@tune.de
www.tune.de



Outside of Germany please contact your local distributor.



BORN IN THE BLACK FOREST BUILT TO ENJOY NATURE



There is no need to say, carbon cup and saucer, a must have for a leightweight fan.

Material	carbon
Volume	420 ml
ø Cup	11,5 cm
ø Saucer	16,0 cm
Weight	270 g

The cup is tested for food safety.



Instructions

- Our cup was tested for food safety, we nonetheless recommend to rinse the cup at least 3 times with boiling water.
- Before every use check the cup for damages. If the cup has cracks, is broken or damaged otherwise do not use the cup anymore.
- The cup can be used to serve food and beverages, it also can be used to serve hot beverages and food.
- When using the saucer as a plate pay attention to not damage the surface (e.g. by a knife).
- Please do not put the Tune Ruhrpott in the dishwasher, for cleaning water and detergent are sufficient.