



### Reprogramming Wireless Remote Control for Winches

This bulletin covers the following Champion Power Equipment models:

All Wireless Remote Winches

Note: Read instructions completely before performing service.

1. Press and hold the ON/OFF button for 3 seconds (LED will turn on) to turn the remote ON.
2. Press and hold the IN and OUT buttons for 20 seconds (LED will flash 1x per second) to clear current programming.
3. Release the IN and OUT buttons when the LED is on and no longer flashing (after 20 flashes).
4. Press and hold the IN and OUT button for 3 seconds. LED will turn off and then back on. When the LED is back on, the remote has been programmed.

If you have any questions regarding the previous procedure, please contact our technical department Monday – Friday from 8:30AM – 5:00PM PST at 877-338-0999.

If you have any questions, please contact Champion Power Equipment:

Champion Power Equipment, Inc.  
12039 Smith Ave.  
Santa Fe Springs, CA 90670

Phone: 1-877-338-0999

Email: [tech@championpowerequipment.com](mailto:tech@championpowerequipment.com)