


TURN ON



Step 1

Locate the battery zipper pocket and the power cable.

Step 2

Connect the power cable to the battery port.

Step 3

Press and hold each button for **THREE seconds** to activate the corresponding heating zones.*



Controls heating in the left & right pockets, middle back and collar areas.



Controls heating in the left & right arms.

or



Controls heating in the left & right pockets.

CONTROL THE HEAT

Press each button to cycle through different heat modes of the corresponding heating zones.



High
Solid red




Medium
Solid white



Low
Solid blue

TURN OFF



Press and hold each power button for **THREE seconds** until the light turns off.*

*Power buttons may differ depending on the style of apparel.

Reach us at:
1 (702) 751-7639
support@ororowear.com

SCAN FOR LATEST
ONLINE VERSION
www.ororo.com

