



 When there is a app update you will get a message. Press **OK** to start update.




 You may also receive the following message. Press **OK** to start update.





You will see a loading icon.






DISH POS App update



Click on **Install** to get the update.








DISH POS App update



Press on **Open**.



 That's it. You're done.





Scan to go to the interactive player