

1 Remove this instruction sheet from the fork and set to the side.


2 Remove thru axle from the box with the charger.

3 Lay bike gently on the driveside* OR have a friend lift the bike by the handlebars to raise the front fork off the ground.



4 Remove the plastic slider from between the two front brake pads. This slider is used to prevent damage during shipping.

*Be mindful to not damage the derailleur or other drivetrain components when laying the bike on the side.

OPTION 1





OPTION 2





5 Install the front wheel by aligning the disc brake with the caliper brake pad slot.

6 Slide the thru axle into the fork from the disc brake side. Push in until there is a firm stop and 0.25" gap between fork and thru axle endcap.



7 Align the quick release lever with the cutout in the thru axle endcap. Begin turning the lever clockwise, keeping the lever open and in the slot.

8 When you cannot screw the thru axle in any further, close the lever by folding it 180 degrees. There should be resistance building when the lever is closed, if there is no resistance repeat steps 6-8 again.



For video instructions on how to perform this installation, see our first ride video at:

[LectriceBikes.com/first-ride-videos](https://www.lectricebikes.com/first-ride-videos) | [help.LectriceBikes.com](https://www.lectricebikes.com/help)