



# WARNING



LITHIUM-ION BATTERY

TO REDUCE THE RISK OF INJURY, USER MUST READ INSTRUCTION MANUAL

- Do not charge with an unspecified charger.
- Do not disassemble this device or attempt to re-purpose or modify it in any manner.
- While charging your phone your Power Pod and phone should be in a well-ventilated area. Do not place under a blanket, pillow, your body, or in a purse, bag, or car.
- Store product in a cool and dry place.
- Do not expose to high temperatures.
- Do not submerge in water.
- Misuse, dropping, or excessive force may cause product damage.
- Turn off the Power Pod when not in use.
- If there is any damage to the device such as dents, punctures, tears, deformities, bulges, or corrosion due to any cause, discontinue use.



SCAN QR CODE TO READ ALL  
IMPORTANT SAFETY INSTRUCTIONS  
BEFORE FIRST USE

Customer Service

Email	Phone	Web
help@getcasely.com	+1 877-795-1249	www.getcasely.com/contact-us

WARNING

POWER POD IMPORTANT SAFETY INSTRUCTIONS

Read all instructions and warnings prior to using this product. Improper use of this product may result in product damage, excess heat, toxic fumes, fire or explosion, for which damages you (“Purchaser”), and not Casely, Inc (“Manufacturer”) are responsible.

When using this product, basic precautions should always be followed, including the following:

1. While charging your phone with your Power Pod, do not place your phone under a blanket, pillow, your body, a purse, or a bag. While charging your phone your Power Pod and phone should be in a well-ventilated area.
2. Before using your Power Pod for the first time, fully charge it (so that clicking the charge status button lights all 4 status LEDs)
3. Store product in a cool and dry place.
4. Do not store device in high-temperature environment, including heat caused by intense sunlight or other forms of heat. Do not place device in fire or other excessively hot environments. Exposure to fire or temperature above 212°F (100°C) may cause explosion.
5. This product should be operated only in open-air conditions. It should not be operated in an enclosed, unventilated space such as a carrying bag, pocket, purse, car or bedding. Failure to follow these instructions may damage the product by overheating.
6. Use of a power supply or charger not included by Casely may result in a risk of fire or injury to persons.

7. Do not leave your Power Pod charging overnight or for extended periods of time. It is recommended to only charge your Power Pod for up to 3 hours.
8. Avoid recharging the Power Pod and iPhone at the same time.
9. Do not put fingers or hands into the product.
10. Do not disassemble this device or attempt to re-purpose or modify it in any manner.
11. For questions or instructions for the various ways to charge this device, refer to the illustrations in this instruction manual.
12. Do not disconnect the Power Pod battery from a connected device while the device is charging—wait until the device is fully charged.
13. Be cautious of drops, bumps, abrasions, or other impacts to this device. If there is any damage to the device such as dents, punctures, tears, deformities, or corrosion due to any cause, discontinue use. Contact Manufacturer or dispose of it in an appropriate manner at your local battery-recycling center.
14. Do not use the battery case in excess of its output rating. Overloading outputs above rating may result in a risk of fire or injury to persons.
15. Do not attempt to replace any part of this device.
16. Operating temperature should be between 32°F to 104°F / 0°C to 40°C. High temperatures will reduce charging speed and restrict power, which is something that happens to all wireless chargers. It is recommended that you charge your device in environments with temperatures below 25°C / 77°F. Note: When your Power Pod exceeds the tempera-

- ture limit, the battery level indicator will turn off. Let your Power Pod cool down before use.
17. Do not disassemble the product. Take it to a qualified service person when service or repair is required. Incorrect reassembly may result in a risk of fire or injury to persons.
18. If the product is not used for long periods of time, you should change and discharge it once every three months.
19. When charging a device, the product may feel warm, this is a normal operating condition and should not be cause for concern.
20. In normal conditions, the battery performance will decline over several years.
21. Do not dispose of the product in heat or fire.
22. Do not expose the battery case to rain or snow.
23. Do not clean the product with harmful chemicals or detergents.
24. Misuse, dropping, or excessive force may cause product damage.
25. When disposing of secondary cells or batteries, keep cells or batteries of different electrochemical systems separate from each other.
26. Be aware that a discharged battery may cause fire or smoke. Tape the terminals to insulate them.
27. If this device is accessible to or may be used by a minor, purchasing adult agrees to be solely responsible for providing supervision, instruction, and warnings. Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse by a minor.

28. All products have gone through a thorough quality assurance inspection. If you find that your device is excessively hot, is emitting odor, is deformed, abraded, cut or is experiencing or demonstrating an abnormal phenomenon, immediately stop all product use and contact Manufacturer.
29. Never dispose of batteries in the garbage. Disposal of batteries in the garbage is unlawful under state and federal environmental laws and regulations. Always take used batteries to your local battery-recycling center. Find a battery recycling location near you: call2recycle.org
30. Switch off the portable battery when not in use.
31. To comply with FCC/IC RF exposure compliance requirements, the wireless charger must be used with a separation distance of at least cm from all persons.
32. This device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.
33. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

SAVE THESE INSTRUCTIONS

Legal

Manufacturer shall not in any way be liable to you or to any third party for any damages you or any third party may suffer as a result of use, intended or unintended, or misuse of this product in conjunction with any device or accessory other than the appropriate device for which this product is designed. Manufacturer will not be responsible for any damages you or any third party may suffer as a result of misuse of this product as outlined above.

Purchaser agrees to defend, indemnify, and hold Manufacturer harmless for any claims or damages arising from unintended use or misuse, including use with an unintended device. This device complies with part 15 of the FCC Rules and RSS-Gen of IC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures (continued on page 7):

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced technician for help.

CAUTION: To comply with the limits of the Class B digital device, pursuant to Part 15 of the FCC Rules, this device must be used with certified peripherals and shielded cables. All peripherals must be shielded and grounded. Operation with non-certified peripherals or non-shielded cables may result in interference to radio or reception.

MODIFICATION: Any changes or modifications of this device could void the warranty.

STATEMENT OF COMPLIANCE Hereby, Casely, Inc. declares that the radio equipment wireless charging base is in compliance with Directive 2014/53/EU.

WEEE STATEMENT: All of our products are marked with the WEEE symbol; this indicates that this product must NOT be disposed of with other waste. Instead it is the user's responsibility to dispose of their waste electrical and electronic equipment by handing it over to an approved re-processor, or by returning it to Casely, Inc. for reprocessing. For more information about where you can send your waste equipment for recycling, please contact Casely, Inc. or one of your local distributors. THIS DEVICE CONFORMS TO UL STD. 60950- 1. CERTIFIED TO CSA STD. C22.2 NO. 60950-1. CONFORMS TO UL SUBJECT 2056.



Casely

GETCASELY.COM

IMPORTANT SAFETY INSTRUCTIONS



SCAN QR CODE TO READ ALL  
IMPORTANT SAFETY INSTRUCTIONS  
BEFORE FIRST USE

Customer Service

Email	Phone	Web
help@getcasely.com	+1 877-795-1249	www.getcasely.com/contact-us